

| USB Port Printer List |                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Brand                 | Type                    | Model                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>HP</b>             | Deskjet                 | 640C, 656C, 845C, 920C, 948C ,960C, 990CXI, 995C, 125C, 1180C, 3320, 3420, 3425, 3535 , 3650 , 5625                                                                                                                                                                                                                                                                                                                                                                   |
|                       | Inkjet                  | DeskJet5610, DeskJet5650, DeskJet5850, CP1700                                                                                                                                                                                                                                                                                                                                                                                                                         |
|                       | Laserjet                | 1200, 2200, 2200D, 1500(USB 2.0)                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>LexMark</b>        |                         | Z13, Z33, Z43, Z53, Z25, Z35, Z45, 4039 10R, 5700, Optra Color 45<br>Optra C710, Optra E, E+, E310, Optra K1220, Optra M410, M412, Optra N,<br>Optra R+, Optra S1250, Optra S1855, Optra SC-1275, Optra SE-3455, OptraT614<br>Optra W810                                                                                                                                                                                                                              |
| <b>Canon</b>          |                         | S100SP, S200SP, S300, S330, S400SP, S520, S600, S6300, S750, S450..<br>S4500, S9000, PIXUS 850i, BJC55, BJC85, I850                                                                                                                                                                                                                                                                                                                                                   |
| <b>EPSON</b>          | Stylus                  | C41UX, C405, C60, C61, C80, C42UX, RX510,                                                                                                                                                                                                                                                                                                                                                                                                                             |
|                       | Photo                   | R310, 720, 810, 820, 830, 830U, 890, 900, 1280, 1290, PM860PT,<br>CC550L, CC570L, CL750, CL760, MC-2000, PM680C, PM-720C, PM-730C,<br>PM-740C, PM740DU, PM-D750, PM-780CS, PM-790PT, PM-800C, PM-800DC,<br>PM-820C, PM-820DC, PM-830C, PM-840C, PM-850PT, PM-860PT, PM-870C,<br>PM-890C, PM-G900, PM-920C, PM-930C, PM-940C, PM-950C, PM-970C,<br>PM-980C, PM-D1000, PM-2200C, PM-3300C, PM-3500C, PM-3700C,<br>PM-4000PX , PM-A850, PM-D750, PM-G700, PM-G800, E-100 |
|                       | Laser                   | PX-V500, PX-V600, PX-V700, PX-G900, 900, 1160, 2200, LP-1200, LP-1300<br>LP-1400, LP1500C, LP-2000C, LP-2400, LP-2500, LP-6100. LP-7000C,<br>LP-7500, LP-7700, LP-7800, LP-7900, LP-8900, LP-9000B, LP-9000C,<br>LP-9100, LP-9400, LP-9500C, LP-9800C                                                                                                                                                                                                                 |
|                       | All in One<br>Officejet | PM-A850, CC-600PX                                                                                                                                                                                                                                                                                                                                                                                                                                                     |